



Cafe Series Parasol


Owners Manual





CAFE SERIES PARASOL

The Cafe Series is manufactured using high quality materials and fabrics and is designed to give you many years of trouble free use and enjoyment. The following information how to operate your Nova parasol correctly. Please follow these instructions as they are designed to assist operation and prolong the life of the parasol.



CAFE SERIES PARASOL RANGE



Post				
Frame Specifications	2m sq	3m sq	2.8m oct	4.2m oct
(outside diameter x thickness x length (mm))	40 x 2.0 x 2600	50 x 2.0 x 2900	40 x 2.0 x 2600	50 x 2.0 x 2900
Long arms (mm)	18 x 24 x 1.2	18 x 30 x 1.2	18 x 24 x 1.2	18 x 30 x 1.2
Dimensions of closed parasol				
a: Height (mm)	2600	2900	2600	2900
b: Closed canopy clearance (mm)	1000	750	1000	750
Dimensions of open parasol				
c: Height (mm)	2600	2900	2600	2900
d: Canopy edge height (mm)	2050	2100	2050	2100
Weight				
Parasol (unboxed) (kg)	6.5	14.5	9.5	16.5
Packaging Dimensions				
Total Length (inc post) (mm)	1670x 205 x 205	2960 x 230 x 230	1670 x 205 x 205	2960 x 230 x 230
Weight (boxed parasol) (kg)	9.5	18	13	21.5
Wind Guidance**				
Install wind rating (km/h)	60	50	60	50

**The above wind speeds are provided as a guide only. Refer to our website and Product Owner Manual provided with the parasol for more information. The product warranty does not cover wind damage regardless of wind speed.

**100KM wind rating applies to 3m Square size only.

INSTALLATION OPTIONS

You can either use your umbrella with a freestanding base, or alternatively, you can install it using an in-ground fitting.

Base Options:



Cafe Series Wheel Base



Galvanised Steel Premium Base
(35kg or 45kg)



Concrete Ring Plate
(14kg or 19kg)



Inground Base



Steel Base Plate
(14kg or 19kg)



Sand Bag Weights

SETTING UP CAFE SERIES PARASOL

Opening The Parasol For The First Time:

When the parasol is being opened for the first time, ensure the velcro strap and all the packaging has been removed. There may be some packaging material on the arms underneath the fabric canopy - partially open the parasol and get in underneath the fabric canopy to remove all this packaging before fully opening the parasol.



IMPORTANT: The parasol support arms are fitted with **PLASTIC SLIDING SPACERS**. The spacers help to keep the arms spread apart when the parasol is closed. This will make it easier to open next time it is used and to prevent the arms getting “stuck” down when trying to open the parasol. When the parasol is packaged for shipping, the spacers are not engaged and are located at the lower end of the support arms. **Before using the parasol for the first time you must engage the spacers into the pre-drilled locking holes by sliding each spacer into position up the parasol arms. A barrel bolt is supplied to secure each spacer into place.**


OPERATING CAFE SERIES PARASOL

Step One: Slide parasol centre post into base plate. Secure the parasol by inserting the locking bolt through the mast hole and spigot, then tighten up the nut.

Step Two: Remove the velcro strap around the canopy and open the parasol by pulling down on the pulley rope. Bubble wrap may need to be removed from top of the pole.

Step Three: Slide stop pin into desired height setting on the centre pole.

Step Four: Secure the canopy by wrapping the rope pulley around the centre post anchor point in a figure of 8 motion.



CLOSING PARASOL FOR LONG TERM STORAGE

Step One: Group the four fabric panels and roll together towards the frame. Fold the remaining panels over the rolled panels one by one, alternating from left to right.

Step Two: Secure the folded panels in place with the velcro strap by wrapping it around the parasol tightly.

Step Three: Place the unzipped cover bag around and over the parasol.

Step Four: Zip the cover bag shut using the attached pull cord.



CARE AND MAINTENANCE

You will get maximum benefit from your parasol when you use it in accordance with our instructions and in the weather conditions for which it was designed.

General Information:

- Do not leave the parasol open when unattended, particularly in windy conditions.
- The parasol should be closed and securely strapped in strong winds and adverse weather conditions.
- Always secure your parasol to an appropriate footing/base.
- Any modifications to your parasol, except those made by Instashade Ltd. may invalidate the warranty.
- Make sure the parasol is dry and clean prior to storing away for extended periods of time to prevent mould from developing.
- Be careful when closing the parasol to ensure that the canopy does not get caught or “pinched” by the parasol arms. This is particularly important before storing the parasol away for extended periods of time or if the parasol is to be laid horizontally for storage. Damage to the fabric caused by “pinching” is not covered by warranty.

Maintenance Instructions:

- In coastal or metropolitan environments it is beneficial to wash off any dirt, pollen sand salt residue from the parasol frame and fabric using a hose or soft bristle brush.
- Periodic spraying of silicon spray into the gear box through the winder hole will assist operation and prolong the life of the winder unit.
- A protective cover bag is advisable to use if the parasol is not to be used for some time. The parasol must be dry before being packed in a cover bag.
- Inspect the installation fitting/base on a regular basis and tighten as necessary.
- Periodically check all the connecting brackets and joints of the parasol to ensure that all bolts/fittings are tight and secure. Tighten any bolts as required.



WARRANTY

INSTASHADE PARASOLS ECLIPSE, AURORA, NOVA ALL COME WITH THE FOLLOWING WARRANTIES:

- 3 year NO FADE olefin canvas
- 10 year NO FADE on acrylic (Eclipse/Nova)

The warranty covers faulty materials and faulty workmanship only. Wind damage is not covered by this warranty.

WARRANTY TERMS:

- This warranty does not cover damage caused by wind or adverse weather conditions, fair wear and tear, accidents or misuse.
- This warranty is valid only if the parasol is installed and operated as per the instructions in this manual.
- This is a back base warranty. In the case of repairs to the parasol being required (regardless of whether the repairs are covered under warranty) the cost of transportation to/from Instashade Ltd. Is to be paid by the claimant.
- Installation fittings and spigots are made using galvanised steel. Rust is a natural part of the aging process of all steel, based materials and is therefore not considered a defect and is not covered under warranty.
- This warranty is given by Instashade Ltd. No person has the authority to change or add to these obligations and liabilities without Instashade Ltd. approval in writing.
- Instashade Ltd. reserves the right to determine whether fault is caused by faulty workmanship, faulty materials or that any part is defective. Where fault is determined, we reserve the right to repair or replace products at our discretion.
- Instashade Ltd. or its authorised agent may offer advice but accepts not responsibility as to the ultimate positioning of the parasol. In the case of installations, the owner is to ascertain position of all underground pipes and electrical wires and notify the installer of any obstacles. Although all care will be taken, no responsibility can be accepted for any damage during installation.
- Any parasol repair, hardware replacement or fabric replacement supplied under the warranty is covered for the time remaining in the original warranty and does not active a new warranty period.
- This warranty applies to the original purchaser only.

FABRIC WARRANTY TERMS:

Our solution dyed acrylic fabrics are guaranteed against:

- Rot or significant loss of strength from normal usage and exposure conditions. It does not apply against any deterioration of any kind due to wind or weather-related damage, misuse, burns, negligence, vandalism, perforations or stains due to environmental pollution and fair wear and tear.
- Loss of colour. Our acrylic canvas fabric is warranted to remain colour-fast to a rating of 7-8 on a 1-8 scale (meaning minimum fading).
- Recasens fabrics are manufactured with only the highest quality raw materials and the most rigorous quality-assurance procedures. Recasens fabrics are covered by a 10 year residential warranty (5 years for commercial use) covering rot and colour fading* in normal environments and conditions of use. The warranty does not cover wear and tear, or wind related damage.

**Colours with red pigmentation (red, orange and yellow etc) will have lower colour fastness than other colours and will show some fading earlier.*



Unit 7 & 8 Tatton Court
Kingsland Grange
Warrington
WA1 4RR

Tel: 01925 859960
Email – info@instashade.co.uk
Web – www.instashade.co.uk